

1/16N "SWAGE-IT"



Sizes: 1/16" Oval and 1/16" Stop Sleeves

Insert sleeve as shown

INSTRUCTIONS

- 1) SWAGE TO .180 DIAMETER MAXIMUM USING BOTH HANDS IF NECESSARY.
- 2) MAKE THREE PRESSES (SWAGED AREAS) PER SLEEVE.

SWAGE-IT